



DOORBRIM™ Rain Diverters

SINGLE DOOR or WINDOW installation instructions on Wood Base Surfaces

Tools Required:		In The Box:
Standard drill 3/16" concrete drill bit Ratchet with 5/16" socket Silicone caulking	Pencil Caulking gun 6' step ladder 48" level Paint (optional)	1 - DOORBRIM rain diverter 7 – Dewalt Ultracon+ 1 3/4" x 1/4" hex flange head fasteners (optional) 9 oz tube Silicone caulking (optional)

NOTE: We recommend that a qualified licensed and insured contractor install your DOORBRIM Rain Diverter.

- 1) Place the rain diverter above your door and position min. vertically 2" above the top of the door when open, level and center horizontally and recommended 6" past each side of the door & frame. Use your rain diverter as a template and mark the 7 screw holes.
- 2) Wearing safety glasses, drill holes with a standard drill and 3/16" drill bit. Apply a bead of silicone caulking to the rear of the mounting flange, below and around the screw holes.
- 3) Attach your Door Canopy to the wall using a ratchet with a 5/16" socket and hex flange head fasteners. Carefully hand tighten the last 1/4" until the rain diverter is seated firmly against the wall in a bed of caulk. **DO NOT OVER TIGHTEN FASTENERS** to avoid risk of damaging the mounting flange! **DO NOT USE a hammer drill, impact wrench or hex head driver,** which will chip off the matching paint color.

As with all cutting tools and fasteners, normal safety precautions should be observed when drilling holes to avoid electrical installations, other utilities and reinforcement bars. The wearing of safety glasses by users and persons in the vicinity is required by Federal Law.