



DOORBRIM Awnings™

Single Door Canopy

INSTALLATION INSTRUCTIONS

Masonry, Concrete and Brick Surfaces

Tools Required:		In The Box:
Hammer drill with 7/32 concrete drill bit	Pencil	1 - DOORBRIM Door Canopy
Ratchet with 1/4" socket	Caulking gun	7 - 1 3/4" x #14 Stainless steel concrete fasteners (optional)
Silicone caulking	6' step ladder	7 - Stainless steel bonded washers (optional)
	48" level	
	Paint (optional)	

INSTALLATION INSTRUCTIONS for ELCO Crete-Flex SS4 masonry fasteners:

Elco Crete-Flex fasteners are easily installed with a commercial-grade hammer drill or rotary hammer using a 7/32" ANSI masonry drill bit (actual bit diameter of .229"-.237") and a traditional 1000 installation tool or Crete-Flex Pro installation tool. **As with all cutting tools and fasteners, normal safety precautions should be observed when drilling holes to avoid electrical installations, other utilities and reinforcement bars. The wearing of safety glasses by users and persons in the vicinity is required by Federal Law.**

NOTE: We recommend that a qualified licensed and insured contractor install your DOORBRIM Door Canopy.

- 1) Place the Door Canopy above your door and position vertically 2" above the top of the door when open, level and center horizontally and 6" past each side of the door. Use your Door Canopy as a template and mark the 7 screw holes.
- 2) Wearing safety glasses, drill holes with hammer dill and 7/32" concrete drill bit. Apply a bead of silicone caulking to the rear of the mounting flange, below and around the screw holes. Mount your Door Canopy with stainless steel concrete screws and bonded washers
- 3) Attach your Door Canopy to the wall using a ratchet with a 1/4" socket or nut driver to install the concrete fasteners. Hand tighten the last 1/4" until the Door Hood or Canopy is seated firmly against the wall in a bed of caulk. **DO NOT OVER TIGHTEN FASTENERS** to avoid risk of damaging the mounting flange! **DO NOT USE UNDERSIZED SCREWS.**