



DOORBRIM Awnings™

Single Door Canopy

INSTALLATION INSTRUCTIONS

Aluminum, Vinyl & Wood Cladding over Plywood or OSB Surfaces

Tools Required: Drill with 3/16 drill bit Ratchet with 1/4" hex socket Silicone caulking Pencil	Caulking gun 6' step ladder 48" level Paint (optional)	In The Box: 1 - DOORBRIM Door Canopy 7 - 2" X #14 Wood screws (optional) 7 - Stainless steel bonded washers (optional)
--	---	--

As with all cutting tools and fasteners, normal safety precautions should be observed when drilling holes to avoid electrical installations, other utilities and reinforcement bars. The wearing of safety glasses by users and persons in the vicinity is required by Federal Law.

Note: We recommend that a qualified licensed and insured contractor install your DOORBRIM Door Canopy.

- 1) Place the Door Canopy above your door and position vertically 2" above the top of the door when open, level and center horizontally and 6" past each side of the door. Use your Door Canopy as a template and mark the 7 screw holes.
- 2) Wearing safety glasses, drill holes with 3/16" drill bit. Apply a bead of silicone caulking to the rear of the mounting flange, below and around the screw holes. Mount your Door Canopy with stainless steel wood screws and bonded washers.
- 3) Attach your Door Canopy to the wall using a ratchet with a 1/4" socket or nut driver to install the wood fasteners. Hand tighten the last 1/4" until the Door Canopy is seated firmly against the wall in a bed of caulk. ***DO NOT OVER TIGHTEN FASTENERS*** to avoid risk of damaging the mounting flange! ***DO NOT USE UNDERSIZED SCREWS.***